


# EXPLOSION-DRAWING / SPAREPARTS-OVERVIEW

## EXPLOSIONSZEICHNUNG / ERSATZTEILLISTE



**SPORTSTECH**

**TREADMILL F31**  
**LAUFBAND F31**

Number in explosion drawing	Item number	Description
01	SP_F31_01	Base frame
02	SP_F31_02	Main frame
03	SP_F31_03	Incline frame
04	SP_F31_04	Left side frame
05	SP_F31_05	Right side frame
06	SP_F31_06	Console frame
07	SP_F31_07	Cap for frame
08	SP_F31_08	Wheel for frame
09	SP_F31_09	Foot pad for frame
10	SP_F31_10	Incline motor
11	SP_F31_11	Power cable
12	SP_F31_12	Switch
13	SP_F31_13	Cable clip
14	SP_F31_14	Overload switch
15	SP_F31_15	Motor
16	SP_F31_16	Circuit controller
17	SP_F31_17	Roller front
18	SP_F31_18	Running belt 2520x420
19	SP_F31_19	Running deck 575x1120x15
20	SP_F31_20	Roller rear
21	SP_F31_21	Bumper post
22	SP_F31_22	Cushion
23	SP_F31_23	Side rail
24	SP_F10_24	Left rear plastic cover
25	SP_F31_25	Right rear plastic cover
26	SP_F31_26	Motor belt
27	SP_F31_27	Cap for main frame
28	SP_F31_28	Rear wheel
29	SP_F31_29	Motor cover
30	SP_F31_30	Handle rail
31	SP_F31_31L	Left heart sensor kit
31	SP_F31_31R	Right heart sensor kit
32	SP_F31_32	Console plate lower
33	SP_F31_33	Safety spring
34	SP_F31_34	Speaker
35	SP_F31_35	Audio circuit board
36	SP_F31_36	Housing of console upper
37	SP_F31_37	Keyboard plate
38	SP_F31_38	Housing of console lower
39	SP_F31_39	Connecting wire down
40	SP_F31_40	Connecting wire up
41	SP_F31_41	Tube cap
42	SP_F31_42	Gas spring

Number in explosion drawing	Item number	Description
43	SP_F31_43	Display plantin
44	SP_F31_44	Oil cover down
45	SP_F31_45	Socket head cap screws M10x105
46	SP_F31_46	Socket head cap screws M10x40
47	SP_F31_47	Socket head cap screws M8x10
48	SP_F31_48	Flat head socket cap screw M4x8
49	SP_F31_49	Spring waher D4
50	SP_F31_50	Socket head cap screws M12x60
51	SP_F31_51	Self tapping screw ST3x20
52	SP_F31_52	Flat head socket cap screw M3x8
53	SP_F31_53	Socket head cap screws M8x55
54	SP_F31_54	Socket head cap screws M8x16
55	SP_F31_55	Spring waher D12
56	SP_F31_56	Spring waher D8
57	SP_F31_57	Socket head cap screws M8x50
58	SP_F31_58	Flange nut M8
59	SP_F31_59	Self tapping screw ST3x8
60	SP_F31_60	Socket head cap screws M8x35
61	SP_F31_61	Flat head socket cap screw M5x10
62	SP_F31_62	Flat head socket cap Screw M5x25
63	SP_F31_63	Socket head cap screws M8x20
64	SP_F31_64	Socket head cap screws M8x45
65	SP_F31_65	Socket head cap screws M8x55
66	SP_F31_66	Socket head cap screws M8x20
67	SP_F31_67	Flange nut M8
68	SP_F31_68	Spring waher D8
69	SP_F31_69	Flat head socket cap screw M4x12
70	SP_F31_70	Self tapping screw ST3x10
71	SP_F31_71	Self tapping screw ST4x12
72	SP_F31_72	Socket head cap screws M8x40
73	SP_F31_73	Flange nut M10
74	SP_F31_74	Safety key
75	SP_F31_75	Overlay button
76	SP_F31_76	Overlay screen
77	SP_F31_77	Oil tube
78	SP_F31_78	Seal cap
79	SP_F31_79	Wheel rame
80	SP_F31_80	Puls wire
81	SP_F31_81	Display wire
not in drawing	SP_F31_82	Console set
not in drawing	SP_F31_83	Bluetooth app
not in drawing	SP_F31_Carton	Carton
not in drawing	SP_F31_Manual	Manual