


EXPLOSION-DRAWING / SPAREPARTS-OVERVIEW

EXPLOSIONSZEICHNUNG / ERSATZTEILLISTE



SPORTSTECH

CROSSTRAINER CX2

Number in explosion drawing	Item number	Description
1	SP_CX2_01	Console
2	SP_CX2_02	Screw M5xP0.8x12L
3	SP_CX2_03	Flat washer D5.5xD12x2T
4	SP_CX2_04	Ipad holder
5	SP_CX2_05	Screw M5
6	SP_CX2_06	Computer cable
7	SP_CX2_07	Computer holder Lower cover
8	SP_CX2_08	Screw M7xP1.0x30L
9	SP_CX2_09	Spring washer D7.1x1.5T
10	SP_CX2_10	Flat washer D7xD12x1T
11	SP_CX2_11	Spring washer D8
12	SP_CX2_12	Computer holder cover
13	SP_CX2_13	Central axle cover
14	SP_CX2_14	Central axle cover
15	SP_CX2_15	Handlebar post
16	SP_CX2_16	Screw M8xP1.25x16L
17	SP_CX2_17	Handlebar post jacket
18	SP_CX2_18	Decorative cover
19	SP_CX2_19	Handlebar foam
20	SP_CX2_20	Fixed handlebar D22.2x2Tx900L
21	SP_CX2_21	Pulse cable
22	SP_CX2_22	12B pulse grip
23	SP_CX2_23	Screw ST3.5x20L
24	SP_CX2_24	End cap
25	SP_CX2_25	Central axle D17x350 M8
26	SP_CX2_26	Plastic bushing D17xD32x15L
27	SP_CX2_27	Wavy washer D17.5xD25x0.3T
28	SP_CX2_28	Right pedal arm
29	SP_CX2_29	Bearing 6003
30	SP_CX2_30	Flat washer D8.5xD25x2T
31	SP_CX2_31	Screw M8xP1.25x20L
32	SP_CX2_32	Handlebar cover
33	SP_CX2_33	Handlebar cover
34	SP_CX2_34	Wavy washer D12.5xD18x0.5T
35	SP_CX2_35	Screw M6x20L
36	SP_CX2_36	Screw M8xP1.25x50L
37	SP_CX2_37	Nylon nut M8
38	SP_CX2_38	Semi-circle washer D8xD19x2T
39	SP_CX2_39	Left movable handlebar
40	SP_CX2_40	Handlebar foam
41	SP_CX2_41	Mushroom end cap
42	SP_CX2_42	Screw M5x16
43	SP_CX2_43	Screw ST2.9x20
44	SP_CX2_44	Left pedal arm 3/16"x3/4"
45	SP_CX2_45	Bearing 6001
46	SP_CX2_46	Sleeve D8.1xD12x38L
47	SP_CX2_47	C shape clip D11xD13.6x1T
48	SP_CX2_48	Screw M8xP1.25x55L
49	SP_CX2_49	Flat washer D8xD19x2T
50	SP_CX2_50	Left pedal tube
51	SP_CX2_51	Tube decorative cover
52	SP_CX2_52	Tube decorative cover
53	SP_CX2_53	Front stabilizer
54	SP_CX2_54	Screw M8x40LxS12L
55	SP_CX2_55	Transport wheel
56	SP_CX2_56	Screw M6x10L
57	SP_CX2_57	Flat washer D6.5xD16x2T
58	SP_CX2_58	Stabilizer end cap
59	SP_CX2_59	Locking pad 3T
60	SP_CX2_60	Lever adjuster M8
61	SP_CX2_61	Rear stabilizer
62	SP_CX2_62	Left pedal
63	SP_CX2_63	Wheel cover cross
64	SP_CX2_64	Wheel cover
65	SP_CX2_65	Decorative cover of pulley
66	SP_CX2_66	Left chain cover
67	SP_CX2_67	Left decorative cover
68	SP_CX2_68	Bearing 2203
69	SP_CX2_69	Main frame

Number in explosion drawing	Item number	Description
70	SP_CX2_70	Belt 510J6
71	SP_CX2_71	Motor
72	SP_CX2_72	Magnetic set
73	SP_CX2_73	Screw M8xP1.25x55L
74	SP_CX2_74	Flat washer D8xD19x2T
75	SP_CX2_75	Pulley D289x6
76	SP_CX2_76	Screw M6xP1.0x16L
77	SP_CX2_77	C shape clip D43.5xD37.3x1.5T
78	SP_CX2_78	Nylon nut M6
79	SP_CX2_79	Spring washer D6.1x1.6T
80	SP_CX2_80	Axle
81	SP_CX2_81	Screw M8x20L
82	SP_CX2_82	Idler wheel
83	SP_CX2_83	Hex nut 3/8"-26x4.5T\
84	SP_CX2_84	Screw M6x10
85	SP_CX2_85	Idler pressing welding
86	SP_CX2_86	Idler spring
87	SP_CX2_87	Wavy washer D12.5xD18x1.5T
88	SP_CX2_88	Battery Ni-MH AA2000mAhx5 6Vx1
89	SP_CX2_89	Bearing 6901
90	SP_CX2_90	Bearing 6001
91	SP_CX2_91	C shape clip D12
92	SP_CX2_92	Right chain cover
93	SP_CX2_93	Right decorative cover
94	SP_CX2_94	Right pedal tube
95	SP_CX2_95	Right Pedal
96	SP_CX2_96	Sensor
97	SP_CX2_97	Sensor supporter
98	SP_CX2_98	Screw M5x10
99	SP_CX2_99	Bearing 6004
100	SP_CX2_100	Flat washer D20.3xD30x0.5T
101	SP_CX2_101	Wavy washer D20.5xD30x0.3T
102	SP_CX2_102	C shape clip D18.5xD22.5x1T
103	SP_CX2_103	Battery cable 750L
104	SP_CX2_104	Cable lower
105	SP_CX2_105	Right movable handlebar
106	SP_CX2_106	Screw
107	SP_CX2_107	End cap
108	SP_CX2_108	Screw
109	SP_CX2_109	Flat washer D8xD22x2T
110	SP_CX2_110	Flat washer D4.5xD16x1.5T
111	SP_CX2_111	Screw ST3.9x20L
112	SP_CX2_112	Screw 3/16"x3/4"
113	SP_CX2_113	Nut M10
114	SP_CX2_114	Flat washer D6xD13x1T
115	SP_CX2_115	Screw ST2.9x8L
116	SP_CX2_116	Flat washer D6.5xD13x1.5T
117	SP_CX2_117	Wavy washer D10.2xD13x0.3T
118	SP_CX2_118	Flat washer D8xD22x1T
119	SP_CX2_119	Spring of magnetic set D1xD8.5x48L
120	SP_CX2_120	M51 magnetic core
121	SP_CX2_121	Connecting wire-motor & mcb 350L
122	SP_CX2_122	Hexagon wrench 6mmx30mmx184mm
123	SP_CX2_123	Sleeve wrench 13.14 cross
124	SP_CX2_124	Bottle holder
125	SP_CX2_125	Tablet holder
126	SP_CX2_126	Pedal knob
127	SP_CX2_127	Flywheel
128	SP_CX2_128	Electrical Generating spindle
129	SP_CX2_129	Nut 3/8"-26x7T\
130	SP_CX2_130	Battery box
131	SP_CX2_131	Screw M5x10L
132	SP_CX2_132	MCB B801
133	SP_CX2_133	Screw M4x10L
not in drawing	SP_CX2_134	Handlebar set
not in drawing	SP_CX2_135	Sticker
not in drawing	SP_CX2_Carton	Carton
not in drawing	SP_CX2_Manual	Manual
not in drawing	SP_CX2_Screw set	Screw and tool set