



EXPLOSION-DRAWING / EXPLOSIONSZEICHNUNG



Crosstrainer

CX608

No. in explosion drawing	Item no.	Descriptions
1	SP_CX608_v2_001	Main Frame with bearing
2	SP_CX608_v2_002	Left Foot Tube (2+36)
3	SP_CX608_v2_003	Right Foot Tube (2+36)
4	SP_CX608_v2_004	Left Handrail Arm with bearing
5	SP_CX608_v2_005	Right Handrail Arm with bearing
6	SP_CX608_v2_006	Left Handrail Arm (6+12+13)
7	SP_CX608_v2_007	Right Handrail Arm (7+12+13)
8	SP_CX608_v2_008	Front Post
9	SP_CX608_v2_009	Handlebar (9+64+65+66)
10	SP_CX608_v2_010	Front Stabilizer
11	SP_CX608_v2_011	Rear Stabilizer
12	SP_CX608_v2_012	Handrail End Cap Ø32x1.5
13	SP_CX608_v2_013	Handrail Foam Grip Ø31x27x480
14	SP_CX608_v2_014	Bolt M6x35
15	SP_CX608_v2_015	Arc Washer Ø6xØ12x1.0
16	SP_CX608_v2_016	Nut M6
17	SP_CX608_v2_017	Cap Nut Ø38
18	SP_CX608_v2_018	Bolt M8x20
19	SP_CX608_v2_019	Spring Washer Ø8
20	SP_CX608_v2_020	Big Washer Ø8xØ33x2.0
21	SP_CX608_v2_021	Bearing 6002
22	SP_CX608_v2_022	Bearing 6903
23	SP_CX608_v2_023	Curve Washer Ø17xØ21x0.3
24	SP_CX608_v2_024	Bushing
25	SP_CX608_v2_025	Left Foot Tube Cover
26	SP_CX608_v2_026	Right Foot Tube Cover
27	SP_CX608_v2_027	U Bracket with bearing
28	SP_CX608_v2_028	Bearing 6201
29	SP_CX608_v2_029	Bolt Ø16x68xM10
30	SP_CX608_v2_030	Washer Ø10x Ø20x2.0
31	SP_CX608_v2_031	Nut M10
32	SP_CX608_v2_032	Left Foot Pedal
33	SP_CX608_v2_033	Right Foot Pedal
34	SP_CX608_v2_034	Bolt M6x40
35	SP_CX608_v2_035	Washer Ø6x12x1.0
36	SP_CX608_v2_036	Power Bushing Ø14x Ø10x10
37	SP_CX608_v2_037	Left Pedal Tube Bolt
38	SP_CX608_v2_038	Right Pedal Tube Bolt
39	SP_CX608_v2_039	Bearing 6003
40	SP_CX608_v2_040	Spring Washer Ø20xØ13XB2
41	SP_CX608_v2_041	Left Pedal Tube Nut S19
42	SP_CX608_v2_042	Right Pedal Tube Nut S19
43	SP_CX608_v2_043	Cap Nut S13
44	SP_CX608_v2_044	Bolt M8x50
45	SP_CX608_v2_045	Washer Ø16x8x1.5
46	SP_CX608_v2_046	Nut M8
47	SP_CX608_v2_047	Rear Stabilizer End Cap
48	SP_CX608_v2_048	Front Stabilizer End Cap
49	SP_CX608_v2_049	Bolt M10x65
50	SP_CX608_v2_050	PVC Washer Ø10xØ20X1.5
51	SP_CX608_v2_051	Big Arc Washer Ø25xØ10X1.5
52	SP_CX608_v2_052	Cap Nut M10
53	SP_CX608_v2_053	Bolt S6-M8x40
54	SP_CX608_v2_054	Transportation wheel
55	SP_CX608_v2_055	Big Arc Washer Ø8xØ20X2.0

No. in explosion drawing	Item no.	Descriptions
56	SP_CX608_v2_056	Bottle Holder
57	SP_CX608_v2_057	Washer Ø10xØ5X1.0
58	SP_CX608_v2_058	Screw M5x15
59	SP_CX608_v2_059	8-Level Tension Knob
60	SP_CX608_v2_060	Big Arc Washer Ø20xØ5.2
61	SP_CX608_v2_061	Bolt M5x45
62	SP_CX608_v2_062	Arc Washer Ø8xØ16x1.5
63	SP_CX608_v2_063	Screw ST4.2x20
64	SP_CX608_v2_064	Hand Pulse with wire
65	SP_CX608_v2_065	Handlebar End Cap
66	SP_CX608_v2_066	Handlebar Foam Grip Ø27xØ33x360
67	SP_CX608_v2_067	Bolt M5x10
68	SP_CX608_v2_068	Console
69	SP_CX608_v2_069	Extension Sensor Wire L=1100
70	SP_CX608_v2_070	Self-tapping and self-drilling screws ST4.2x20
71	SP_CX608_v2_071	Tension Cable
72	SP_CX608_v2_072	Left Decorative Cover
73	SP_CX608_v2_073	Right Decorative Cover
74	SP_CX608_v2_074	Screw ST4.2x25
75	SP_CX608_v2_075	Cylindrical bearings Ø40x Ø17x12
76	SP_CX608_v2_076	C clip Ø17x1
77	SP_CX608_v2_077	Crank Pulley
78	SP_CX608_v2_078	Spring Washer Ø6
79	SP_CX608_v2_079	Screw M6x15
80	SP_CX608_v2_080	Belt
81	SP_CX608_v2_081	Left Chain Cover
82	SP_CX608_v2_082	Right Chain Cover
83	SP_CX608_v2_083	Plastic Bolt Ø8x32
84	SP_CX608_v2_084	Left Chain Cover Cap
85	SP_CX608_v2_085	Right Chain Cover Cap
86	SP_CX608_v2_086	Left Crank
87	SP_CX608_v2_087	Right Crank
88	SP_CX608_v2_088	Nut M10x1.25
89	SP_CX608_v2_089	Crank Cap
90	SP_CX608_v2_090	Bolt M6x15
91	SP_CX608_v2_091	Washer Ø6x Ø16x1.2
92	SP_CX608_v2_092	C clip Ø12x1.0
93	SP_CX608_v2_093	Magnetic Plate Axle
94	SP_CX608_v2_094	Magnetic Bracket
95	SP_CX608_v2_095	Magnet
96	SP_CX608_v2_096	Magnet Seat
97	SP_CX608_v2_097	Screw ST2.9*9
98	SP_CX608_v2_098	Spring
99	SP_CX608_v2_099	Bolt M6*45
100	SP_CX608_v2_100	Nut M6
101	SP_CX608_v2_101	Bolt M6*12
102	SP_CX608_v2_102	Washer Ø6*Ø12*1.0
103	SP_CX608_v2_103	Bearing Bracket 1
104	SP_CX608_v2_104	Bearing Bracket 2
105	SP_CX608_v2_105	Limit Plastic Cap
106	SP_CX608_v2_106	Bearing 6001
107	SP_CX608_v2_107	Flywheel
108	SP_CX608_v2_108	Bolt M6*10
109	SP_CX608_v2_109	Idler Wheel
110	SP_CX608_v2_110	Idler Wheel Bracket
111	SP_CX608_v2_111	PC Pad
112	SP_CX608_v2_112	Adjust Bolt M8x75
113	SP_CX608_v2_113	Sensor with Wire L=1800
	SP_CX608_v2	SP_CX608_Carton
	SP_CX608_v2	SP_CX608_Manual

SPAREPARTS-OVERVIEW / ERSATZTEILLISTE