




**EXPLOSION-DRAWING /
EXPLOSIONSZEICHNUNG**

Treadmill

sProRun

No. in explosion drawing	Item no.	Descriptions
1	SP_sProRun_01	Motor cover overlay
2	SP_sProRun_02	Upper motor cover
3	SP_sProRun_03	LED strip cover
4	SP_sProRun_04	LED strip housing
5	SP_sProRun_05	Cross recessed oval head tapping screw ST3x8
6	SP_sProRun_06	LED strip
7	SP_sProRun_07	R shape fastener
8	SP_sProRun_08	Foot pad
9	SP_sProRun_09	Bottom motor cover
10	SP_sProRun_10	Standing feet
11	SP_sProRun_11	Rivet nut M6
12	SP_sProRun_12	Spring washer D8
13	SP_sProRun_13	Hexagon socket oval head bolt M8x16
14	SP_sProRun_14	Hexagon socket oval head bolt M6x35
15	SP_sProRun_15	Truss head tapping screw ST4x12
16	SP_sProRun_16	Electric controller
17	SP_sProRun_17	Truss head screw M6x25
18	SP_sProRun_18	Nylon nut M8
19	SP_sProRun_19	Transportation wheel
20	SP_sProRun_20	Hexagon socket oval head bolt M8x35
21	SP_sProRun_21	Cross recessed oval head tapping screw ST3x10
22	SP_sProRun_22	Power socket
23	SP_sProRun_23	Power switch
24	SP_sProRun_24	Cross recessed truss head screw M5x13
25	SP_sProRun_25	Incline part
26	SP_sProRun_26	Cross recessed oval head tapping screw ST4x12 (Black)
27	SP_sProRun_27	Power cord
28	SP_sProRun_28	Cross recessed oval head tapping screw ST5x20
29	SP_sProRun_29	Remote controller
30	SP_sProRun_30	Rear foot pad
31	SP_sProRun_31	Rivet nut M8
32	SP_sProRun_32	Flange nut M6
33	SP_sProRun_33	Motor belt
34	SP_sProRun_34	Motor
35	SP_sProRun_35	Front roller
36	SP_sProRun_36	Main frame
37	SP_sProRun_37	Reinforced tube
38	SP_sProRun_38	Rear roller
39	SP_sProRun_39	Washer D6
40	SP_sProRun_40	Hexagon socket oval head bolt M6x55
41	SP_sProRun_41	Left end cover
42	SP_sProRun_42	Cross recessed oval head tapping screw ST4.2x16
43	SP_sProRun_43	Right end cover
44	SP_sProRun_44	EVA Tape 28*28*4mm
45	SP_sProRun_45	Z Shape plate
46	SP_sProRun_46	Cross recessed oval head tapping screw BT4x10
47	SP_sProRun_47	Running board
48	SP_sProRun_48	EVA Tape 1000cm*30mm*3mm
49	SP_sProRun_49	Washer D5
50	SP_sProRun_50	Plastic fastner

No. in explosion drawing	Item no.	Descriptions
51	SP_sProRun_51	Cross recessed truss head screw M6x25
52	SP_sProRun_52	Truss head tapping screw ST4x16
53	SP_sProRun_53	Cross recessed truss head screw M6x40
54	SP_sProRun_54	Cross recessed oval head tapping screw ST4x10
55	SP_sProRun_55	EVA tape 1000cm*6mm*1mm
56	SP_sProRun_56	EVA tape 1000cm*15mm*1.5mm
57	SP_sProRun_57	Side rail
58	SP_sProRun_58	Running belt
59	SP_sProRun_59	Washer D8
60	SP_sProRun_60	EMI filter
61	SP_sProRun_61	Lock nut
62	SP_sProRun_62	Main control cable
63	SP_sProRun_63	Wire for EMI
64	SP_sProRun_64	Flangn nut M8
65	SP_sProRun_65	Outer supporting tube cover
66	SP_sProRun_66	Left supporting tube
67	SP_sProRun_67	Inner supporting tube cover
68	SP_sProRun_68	Spring
69	SP_sProRun_69	Truss head tapping screw ST4x12
70	SP_sProRun_70	Truss head screw M5x10
71	SP_sProRun_71	Washer D5
72	SP_sProRun_72	Right supporting tube
73	SP_sProRun_73	Locking knob M8
74	SP_sProRun_74	Computer knob
75	SP_sProRun_75	Hexagon socket oval head bolt M8x30
76	SP_sProRun_76	Tablet holder cover (upper)
77	SP_sProRun_77	Washer D8
78	SP_sProRun_78	Disc washer
79	SP_sProRun_79	Tablet holder cover (bottom)
80	SP_sProRun_80	Upper console cover
81	SP_sProRun_81	Display board
82	SP_sProRun_82	Safety key board
83	SP_sProRun_83	Computer cover (bottom)
84	SP_sProRun_84	Truss head screw M6x10
85	SP_sProRun_85	Handle foam
86	SP_sProRun_86	End cap 20x30mm
87	SP_sProRun_87	Handle frame
88	SP_sProRun_88	Cross recessed oval head tapping screw ST3x8
89	SP_sProRun_89	Key board
90	SP_sProRun_90	Display overlay
91	SP_sProRun_91	Key board overlay
92	SP_sProRun_92	Safety key
93	SP_sProRun_93	Hexagon socket oval head bolt M8x27
94	SP_sProRun_94	Cross recessed truss head screw M5x6
95	SP_sProRun_95	EVA tape 217*91mm

SPAREPARTS-OVERVIEW / ERSATZTEILLISTE