


Laufbänder sWalk Fold



**EXPLOSION-DRAWING /
EXPLOSIONSZEICHNUNG**

SPAREPARTS-OVERVIEW / ERSATZTEILLISTE

No. in explosion drawing	Item No.	Description
1	SP_sWalk_Fold_01	Power cord
2	SP_sWalk_Fold_02	Remote controller
3	SP_sWalk_Fold_03	Overlay
4	SP_sWalk_Fold_04	Truss head tapping screw ST3X8
5	SP_sWalk_Fold_05	Washer D6
6	SP_sWalk_Fold_06	Front LED strip
7	SP_sWalk_Fold_07	Side LED strip
8	SP_sWalk_Fold_08	Upper motor cover
9	SP_sWalk_Fold_09	Display board
10	SP_sWalk_Fold_10	Wire for electric controller
11	SP_sWalk_Fold_11	Power socket
12	SP_sWalk_Fold_12	Earth cable
13	SP_sWalk_Fold_13	Wire for power socket
14	SP_sWalk_Fold_14	Bottom motor cover
15	SP_sWalk_Fold_15	Cross recessed oval head tapping screw ST4x16
16	SP_sWalk_Fold_16	Cross recessed oval head tapping screw ST4.2x13
17	SP_sWalk_Fold_17	Motor cover pad
18	SP_sWalk_Fold_18	Transportation wheel shaft
19	SP_sWalk_Fold_19	Transportation wheel
20	SP_sWalk_Fold_20	Electric controller
21	SP_sWalk_Fold_21	Cross recessed oval head tapping screw ST3x8
22	SP_sWalk_Fold_22	Cross recessed oval head tapping screw ST3x10
23	SP_sWalk_Fold_23	Washer D4
24	SP_sWalk_Fold_24	Fixture band
25	SP_sWalk_Fold_25	Hexagon socket oval head bolt M8x40
26	SP_sWalk_Fold_26	Spring washer D8
27	SP_sWalk_Fold_27	Washer D8
28	SP_sWalk_Fold_28	Lock nut M8
29	SP_sWalk_Fold_29	Motor
30	SP_sWalk_Fold_30	Hexagon socket oval head bolt M8x55
31	SP_sWalk_Fold_31	Motor belt
32	SP_sWalk_Fold_32	Front roller
33	SP_sWalk_Fold_33	Crossbar frame
34	SP_sWalk_Fold_34	Truss head screw M5x10
35	SP_sWalk_Fold_35	Cable grommet
36	SP_sWalk_Fold_36	Front foot pad
37	SP_sWalk_Fold_37	Hexagon socket oval head bolt M8x16
38	SP_sWalk_Fold_38	Flangnut M6
39	SP_sWalk_Fold_39	Right side cover (Front)
40	SP_sWalk_Fold_40	Side sticker (Front)
41	SP_sWalk_Fold_41	Left side cover (Front)
42	SP_sWalk_Fold_42	Main frame (Front)
43	SP_sWalk_Fold_43	Reinforced tube

[illegible]