


## Treadmill sWalk



## EXPLOSION-DRAWING / SPAREPARTS-OVERVIEW EXPLOSIONSZEICHNUNG / ERSATZTEILLISTE

No. in explosion drawing	Item number	Description
2	SP_sWalk_O2	Reinforced tube
3	SP_sWalk_O3	Motor cover up
4	SP_sWalk_O4	Motor cover down
5	SP_sWalk_O5	End cover
6	SP_sWalk_O6	High foot pad
7	SP_sWalk_O7	Top left side rail
8	SP_sWalk_O8	Top right side rail
9L	SP_sWalk_O9L_GR	Side rail left grey
9R	SP_sWalk_O9R_GR	Side rail right grey
9L	SP_sWalk_O9L_RD	Side rail left red
9R	SP_sWalk_O9R_RD	Side rail right red
10	SP_sWalk_10	Bottom left side rail
11	SP_sWalk_11	Bottom right side rail
12	SP_sWalk_12	Rear foot pad
13	SP_sWalk_13	Rectangular tube cap 25 x 25 mm
14	SP_sWalk_14	Motor cover foot pad
15	SP_sWalk_15	Transportation wheel
16	SP_sWalk_16	Transportation wheel shaft
17	SP_sWalk_17	Running belt
18	SP_sWalk_18	Front roller
19	SP_sWalk_19	Rear roller
20	SP_sWalk_20	Running board
21	SP_sWalk_21	Lubrication tube
22	SP_sWalk_22	R shape fastener
23	SP_sWalk_23	Lubrication connector
24	SP_sWalk_24	Lubrication cap
25	SP_sWalk_25	LED strip
26	SP_sWalk_26	LED strip cover
27	SP_sWalk_27	Rail fastener
28	SP_sWalk_28	Motor 220 - 240 V
29	SP_sWalk_29	Plastic bushing
30	SP_sWalk_30	Driving belt PJ356/140J / 5 rips
31	SP_sWalk_31	Display board
32	SP_sWalk_32	Electric controller
33	SP_sWalk_33	LED power board
34	SP_sWalk_34	EMI filter
35	SP_sWalk_35	LED control board
36	SP_sWalk_36	BT MP3 module
37	SP_sWalk_37	Choke
38	SP_sWalk_38	Speaker
39	SP_sWalk_39	Power switch
40	SP_sWalk_40	Cable with connector
41	SP_sWalk_41	Wire for power switch
42	SP_sWalk_42	Ground wire
43	SP_sWalk_43	Hexagon socket oval head olt M8 x 55
44	SP_sWalk_44	Washer D8
45	SP_sWalk_45	Cross recessed oval head tapping screw ST4.2 x 16
46	SP_sWalk_46	Cross recessed truss head screw M6 x 25
47	SP_sWalk_47	Cross recessed truss head screw M6 x 35
48	SP_sWalk_48	Flangnut M6
49	SP_sWalk_49	Cross recessed oval head tapping screw ST4 x 12
50	SP_sWalk_50	Cross recessed oval Head tapping screw ST3 x 8
51	SP_sWalk_51	Truss head tapping screw ST3 x 8
52	SP_sWalk_52	Power cord
54	SP_sWalk_54	Hexagon socket oval head bolt M8 x 30
55	SP_sWalk_55	Nylon nut M8
56	SP_sWalk_56	Cross recessed truss head screw M4 x 12
57	SP_sWalk_57	Spring washer D4
58	SP_sWalk_58	Overlay
59	SP_sWalk_59	Truss head tapping screw ST4 x 16
60	SP_sWalk_60	Cable for LED control board and PCB
61	SP_sWalk_61	Rivet nut
62	SP_sWalk_62	Truss head screw M6 x 25
63	SP_sWalk_63	Truss head tapping screw ST4.2 x 16
64	SP_sWalk_64	Magnetic ring
65	SP_sWalk_65	Standup foot pad
66	SP_sWalk_66	Remote controller
67	SP_sWalk_67	Cross recessed oval Head tapping screw ST4 x 11
68	SP_sWalk_68	Cross recessed oval Head tapping screw ST4 x 16
69	SP_sWalk_69	Wire for EMI filter
Not in drawing	SP_sWalk_Manual	Manual
Not in drawing	SP_sWalk_Accessoires set	Accessoires set
Not in drawing	SP_sWalk_Sticker O1	Warning sticker englisch
Not in drawing	SP_sWalk_Sticker O2	Warning sticker german