

EXPLOSION-DRAWING / SPAREPARTS-OVERVIEW

EXPLOSIONSZEICHNUNG / ERSATZTEILLISTE

SP_WBX300-WBX320_01



SP_WBX300-WBX320_02



SP_WBX300-WBX320_03



SP_WBX300-WBX320_04



SP_WBX300-WBX320_06



SP_WBX300-WBX320_05



SP_WBX300-WBX320_07



SPORTSTECH

WATER SPORT WBX300/320
WASSERSPORT WBX300/320

Number in explosion drawing	Item number	Description
1	SP_WBX300-WBX320_01	Paddle
2	SP_WBX300-WBX320_02	Seat
3	SP_WBX300-WBX320_03	Hand pump
4	SP_WBX300-WBX320_04	Foot leash
5	SP_WBX300-WBX320_05	Backpack
6	SP_WBX300-WBX320_06	Removable
7	SP_WBX300-WBX320_07	Dry bag