


EXPLOSION-DRAWING / SPAREPARTS-OVERVIEW

EXPLOSIONSZEICHNUNG / ERSATZTEILLISTE



SPORTSTECH

SPEEDBIKE SX500

Number in explosion drawing	Item number	Description	Number in explosion drawing	Item number	Description
01	SP_SX500_01L	Left pedal	46	SP_SX500_46	Axis D20x162
01	SP_SX500_01R	Right pedal	47	SP_SX500_47	Long fixing tube D25xD20.2x41.2
02	SP_SX500_02	End cap 1 D76	48	SP_SX500_48	Short fixing tube D25xD20.5x12
03	SP_SX500_03	Carriage bolt M10x90	49	SP_SX500_49	Inner chain cover 708x97x756
04	SP_SX500_04	Rear stabilizer	50	SP_SX500_50	Belt 5PK1180
05	SP_SX500_05	Arc washerD10	51	SP_SX500_51	Belt wheel D200x24
06	SP_SX500_06	Domed nut GB/T 802-1988 M10	52	SP_SX500_52	Nut M12x1.25 H=6
07	SP_SX500_07	Carriage bolt M10x90	53	SP_SX500_53	Flat washer 3
08	SP_SX500_08	Bolt M8x40	54	SP_SX500_54	Fixing bolt M6x54
09	SP_SX500_09	Bearing 608ZZ	55	SP_SX500_55	Pull out the fixed piece
10	SP_SX500_10	Vertical seat post	56	SP_SX500_56	Nut M6
11	SP_SX500_11	End cap 2 38x38x2.0	57	SP_SX500_57	Fixing tube D25xD20.2x48.2
12	SP_SX500_12	Seat pots	58	SP_SX500_58	Belt collar D80x72
13	SP_SX500_13	Seat DD-6619	59	SP_SX500_59	Screw 10 ST4.8x13
14	SP_SX500_14	Stopper D52x39 M8	60	SP_SX500_60	Spring washer 2
15	SP_SX500_15	Front stabilizer	61	SP_SX500_61	FlywheelD453c20
16	SP_SX500_16	Main frame	62	SP_SX500_62	Flywheel shaft D25x160
17	SP_SX500_17	Handlebar post	63	SP_SX500_63	Bolt 9 M5x10
18	SP_SX500_18	Handlebar	64	SP_SX500_64	Spring washer 1
19	SP_SX500_19	Left shape knob M10x25	65	SP_SX500_65	Flast washer 1
20	SP_SX500_20	Flat washer 1 D45xD10.5x4	66	SP_SX500_66	Fixing nut M20x1.0
21	SP_SX500_21	Pu wheel D69x23	67	SP_SX500_67	Woolly block 153x16x4
22	SP_SX500_22	Fixing nut 3 M20x1.0	68	SP_SX500_68	Bolt 7 M6x15
23	SP_SX500_23	Washer 2 M10	69	SP_SX500_69	Bolt 8 M6x12
24	SP_SX500_24	Nut M8	70	SP_SX500_70	Adjusting metal 117x14.5xD1.5
25	SP_SX500_25	Bolt 1 M6x6	71	SP_SX500_71	Block 161x21x19
26	SP_SX500_26	Left shape knob M16x1.5 X20mm	72	SP_SX500_72	EVA paddle 95x16x9
27	SP_SX500_27	Bolt 1 M8x16	73	SP_SX500_73	EVA paddle 50x20x4
28	SP_SX500_28	Fixing nut 1 M12x1.25 H=8MM	74	SP_SX500_74	Bolt 2 M6x16
29	SP_SX500_29	Crank end cap D28x6.5	75	SP_SX500_75	Big gasket D16xD6
30	SP_SX500_30	knob D60x113	76	SP_SX500_76	Console
31	SP_SX500_31	Nut - GB/T 41-2000 M10	77	SP_SX500_77	Pulse
32	SP_SX500_32	Twist the fixing D20x34	78	SP_SX500_78	Screw 5
33	SP_SX500_33	Left crank 170x15	79	SP_SX500_79	Bolt 3 M5x10
34	SP_SX500_34	Spring 1 18x62	80	SP_SX500_80	Flat washer
35	SP_SX500_35	Bearing 6004ZZ	81	SP_SX500_81	Support sheet 110x60x2
36	SP_SX500_36	Right crank 170x15	82	SP_SX500_82	Bolt M6x18
37	SP_SX500_37	Screw rod D13.5x197	83	SP_SX500_83	Hand support 120x65
38	SP_SX500_38	Washer 2 D20xD14x2.0	84	SP_SX500_84	Pulse wire
39	SP_SX500_39	Plastic sleeve 1 38x38x2.0 50x50x2.5	not in drawing	SP_SX500_86	Upper brake set
40	SP_SX500_40	Screw 2 ST4.2x19	not in drawing	SP_SX500_87	Lower brake set
41	SP_SX500_41	Screw 3 ST4.2x19	not in drawing	SP_SX500_88	Sticker
42	SP_SX500_42	Screw 4 ST2.9x9.5	not in drawing	SP_SX500_89	Sensor wire
43	SP_SX500_43	Bolt 1 M6x10	not in drawing	SP_SX500_Carton	Carton
44	SP_SX500_44	Outer chain cover 708x93x756	not in drawing	SP_SX500_Manual	Manual
45	SP_SX500_45	Rubber ring 5x38x9.2	not in drawing	SP_SX500_Screw set	Screw and tool set