




**EXPLOSION-DRAWING /  
EXPLOSIONSZEICHNUNG**

## Rowing machine

WRX1000\_V2

| No. in explosion drawing | Item No.              | Descriptions                                        |
|--------------------------|-----------------------|-----------------------------------------------------|
| 1                        | SP_WRX1000_V2_01      | Console                                             |
| 2                        | SP_WRX1000_V2_02      | Console holder                                      |
| 3                        | SP_WRX1000_V2_03      | Umbrella head cross screw M8 X 12L                  |
| 4                        | SP_WRX1000_V2_04      | Nylon nuts M10 x P1,5 x 10T                         |
| 5                        | SP_WRX1000_V2_05      | Socket cap screw M8 x 1,5 x 75L x S30L              |
| 6                        | SP_WRX1000_V2_06_OAK  | Console adjust board short for oak device           |
| 7                        | SP_WRX1000_V2_06_WN   | Console adjust board short for walnut device        |
| 8                        | SP_WRX1000_V2_07      | Console connect sleeve                              |
| 9                        | SP_WRX1000_V2_08_OAK  | Console adjust board long for oak device            |
| 10                       | SP_WRX1000_V2_08_WN   | Console adjust board long for walnut device         |
| 11                       | SP_WRX1000_V2_09      | Console connect holder                              |
| 12                       | SP_WRX1000_V2_10      | Axle sleeve                                         |
| 13                       | SP_WRX1000_V2_100     | Countersunk hexagon socket screws M8 x P1,25 x 40L  |
| 14                       | SP_WRX1000_V2_101     | Crash pad                                           |
| 15                       | SP_WRX1000_V2_102     | Countersunk hexagon socket screws M8 x P1,25 x 30L  |
| 16                       | SP_WRX1000_V2_103     | Hinge connecting sheet up                           |
| 17                       | SP_WRX1000_V2_104     | Hinge connecting piece down                         |
| 18                       | SP_WRX1000_V2_105     | Hinge connection sleeve D13,5 x D20 x 13L           |
| 19                       | SP_WRX1000_V2_106     | Hinge center axis D13,5 x 372L                      |
| 20                       | SP_WRX1000_V2_107     | Umbrella head hexagon socket screw M8 x P1,25 x 16L |
| 21                       | SP_WRX1000_V2_108     | Saddle                                              |
| 22                       | SP_WRX1000_V2_109_OAK | Saddle holder for oak device                        |
| 23                       | SP_WRX1000_V2_109_WN  | Saddle holder for walnut device                     |
| 24                       | SP_WRX1000_V2_11_OAK  | Frame front support plate for oak device            |
| 25                       | SP_WRX1000_V2_11_WN   | Frame front support plate for walnut device         |
| 26                       | SP_WRX1000_V2_110     | Fixed axle with left and right rollers D16 x 356,5  |
| 27                       | SP_WRX1000_V2_111     | Seat pad left and right roller                      |
| 28                       | SP_WRX1000_V2_112     | Flat washer D8 x D14 x 2T                           |
| 29                       | SP_WRX1000_V2_113     | Roller under seat                                   |
| 30                       | SP_WRX1000_V2_114     | Socket cap screw M8 x 115 x S25L                    |
| 31                       | SP_WRX1000_V2_115     | Roller sleeve under seat D9 x D14 x 16L             |
| 32                       | SP_WRX1000_V2_116     | Cell box                                            |
| 33                       | SP_WRX1000_V2_117     | Umbrella head cross tapping screw ST3,9 x 12L       |
| 34                       | SP_WRX1000_V2_118     | Countersunk hexagon socket screws M8 x 16           |
| 35                       | SP_WRX1000_V2_119     | Open spanner                                        |
| 36                       | SP_WRX1000_V2_12      | Countersunk hexagon screws M8 x P1,5 x 35L          |
| 37                       | SP_WRX1000_V2_120     | Hexagon wrench                                      |
| 38                       | SP_WRX1000_V2_121     | End cap                                             |
| 39                       | SP_WRX1000_V2_122     | Bolt M8 x 30                                        |
| 40                       | SP_WRX1000_V2_123     | Light cover                                         |
| 41                       | SP_WRX1000_V2_124     | Screw                                               |
| 42                       | SP_WRX1000_V2_125     | LED                                                 |

| No. in explosion drawing | Item No.             | Descriptions                                            |
|--------------------------|----------------------|---------------------------------------------------------|
| 43                       | SP_WRX1000_V2_126    | LED                                                     |
| 44                       | SP_WRX1000_V2_127    | LED                                                     |
| 45                       | SP_WRX1000_V2_128    | Open spanner                                            |
| 46                       | SP_WRX1000_V2_129    | Hexagon wrench                                          |
| 47                       | SP_WRX1000_V2_13     | Flat washer D8 x D19 x 6T                               |
| 48                       | SP_WRX1000_V2_14     | Countersunk hexagon screws M8 x P1,5 x 25 x 45L         |
| 49                       | SP_WRX1000_V2_15     | Nylon nut M8 x P1,25 x 7T                               |
| 50                       | SP_WRX1000_V2_16     | Roller frame                                            |
| 51                       | SP_WRX1000_V2_17     | Socket cap screw M10 x 35L                              |
| 52                       | SP_WRX1000_V2_18     | Elastic rope roller sleeve D10,5 x D 15 x 8L            |
| 53                       | SP_WRX1000_V2_19     | Elastic rope roller                                     |
| 54                       | SP_WRX1000_V2_20     | Nylon nut M10 x P1,5 x 9T                               |
| 55                       | SP_WRX1000_V2_21     | Umbrella head hexagon socket screw M6 x P1,0 x 20L      |
| 56                       | SP_WRX1000_V2_22     | L shape sheet 65 x 65 x 90L x 3T                        |
| 57                       | SP_WRX1000_V2_23     | L shape sheet 65 x 65 x 90L x 3T                        |
| 58                       | SP_WRX1000_V2_24     | Frame spring box support plate left (plastic)           |
| 59                       | SP_WRX1000_V2_25     | Frame spring box support plate right (plastic)          |
| 60                       | SP_WRX1000_V2_26     | Steel bars on support plates                            |
| 61                       | SP_WRX1000_V2_27     | Hex nut M6 x P1,0 x 5T                                  |
| 62                       | SP_WRX1000_V2_28     | Pull rope roller fixed shaft D10 x 112L                 |
| 63                       | SP_WRX1000_V2_29     | Pull rope roller                                        |
| 64                       | SP_WRX1000_V2_30     | Bearing 6000                                            |
| 65                       | SP_WRX1000_V2_31     | Circlip for shaft D9,3 x D11,5 x 1T                     |
| 66                       | SP_WRX1000_V2_32     | Roller shaft sleeve D10 x D29 x 23L                     |
| 67                       | SP_WRX1000_V2_33     | Hexagon socket set screws M5 x 5L                       |
| 68                       | SP_WRX1000_V2_34     | Pull rod fixed sleeve                                   |
| 69                       | SP_WRX1000_V2_35     | Countersunk hexagon socket screws M8 x P1,25 x 70L      |
| 70                       | SP_WRX1000_V2_36     | Quick adjustable tower buckle                           |
| 71                       | SP_WRX1000_V2_37     | Countersunk head cross tapping screw ST3,9 x 15L        |
| 72                       | SP_WRX1000_V2_38     | Countersunk hexagon socket screws M8 x P1,25 x 50L      |
| 73                       | SP_WRX1000_V2_39_OAK | Tank support plate for oak device                       |
| 74                       | SP_WRX1000_V2_39_WN  | Tank support plate for walnut device                    |
| 75                       | SP_WRX1000_V2_40     | Circlip for shaft D12,9 x D15,6 x 1T                    |
| 76                       | SP_WRX1000_V2_41     | Puller                                                  |
| 77                       | SP_WRX1000_V2_42     | Drawstring                                              |
| 78                       | SP_WRX1000_V2_43     | Elastic string                                          |
| 79                       | SP_WRX1000_V2_44     | Hexagon nuts M8 x P1,0 x 11T                            |
| 80                       | SP_WRX1000_V2_45     | Flat washer D6,5 x D16 x 2T                             |
| 81                       | SP_WRX1000_V2_46     | Guide ring                                              |
| 82                       | SP_WRX1000_V2_47_OAK | Frame support plate left for oak device                 |
| 83                       | SP_WRX1000_V2_47_WN  | Frame support plate left for walnut device              |
| 84                       | SP_WRX1000_V2_48     | Pad                                                     |
| 85                       | SP_WRX1000_V2_49     | Countersunk hexagon socket screws with M8 x P1,25 x 35L |
| 86                       | SP_WRX1000_V2_50     | Idler wheel                                             |
| 87                       | SP_WRX1000_V2_51     | Countersunk hexagon socket screws M8 x P1,25 x 75L      |

SPAREPARTS-OVERVIEW /  
ERSATZTEILLISTE

## Rowing machine

WRX1000\_V2

| No. in explosion drawing | Item No.             | Descriptions                                               |
|--------------------------|----------------------|------------------------------------------------------------|
| 88                       | SP_WRX1000_V2_52_OAK | Frame support plate right for oak device                   |
| 89                       | SP_WRX1000_V2_52_WN  | Frame support plate right for walnut device                |
| 90                       | SP_WRX1000_V2_53_OAK | Pedal support plate for oak device                         |
| 91                       | SP_WRX1000_V2_53_WN  | Pedal support plate for walnut device                      |
| 92                       | SP_WRX1000_V2_54     | Pedal adjusting pad                                        |
| 93                       | SP_WRX1000_V2_55     | Pedal fixed holder                                         |
| 94                       | SP_WRX1000_V2_56     | Pedal strap                                                |
| 95                       | SP_WRX1000_V2_57     | Shot head cross tapping screw ST4,8 x 14L                  |
| 96                       | SP_WRX1000_V2_58_OAK | Upper frame spring box support plate for oak device        |
| 97                       | SP_WRX1000_V2_58_WN  | Upper frame spring box support plate for walnut device     |
| 98                       | SP_WRX1000_V2_59     | Graphite copper sleeve D20 x D40 x 20L                     |
| 99                       | SP_WRX1000_V2_60     | Stay cord upper roller                                     |
| 100                      | SP_WRX1000_V2_61     | Bearing                                                    |
| 101                      | SP_WRX1000_V2_62     | Socket cap screw M10 x 135L x S20                          |
| 102                      | SP_WRX1000_V2_63     | Flat washer D10,5 x D16 x 2T                               |
| 103                      | SP_WRX1000_V2_64_OAK | Water tank connecting plate for oak device                 |
| 104                      | SP_WRX1000_V2_64_WN  | Water tank connecting plate for walnut device              |
| 105                      | SP_WRX1000_V2_65     | Tank top cover hole plug                                   |
| 106                      | SP_WRX1000_V2_66     | Tank top cover                                             |
| 107                      | SP_WRX1000_V2_67     | Wheel shelf                                                |
| 108                      | SP_WRX1000_V2_68     | Console holder left                                        |
| 109                      | SP_WRX1000_V2_69     | Console holder right                                       |
| 110                      | SP_WRX1000_V2_70     | Umbrella head hexagon socket screw M8 x P1,0 x 35L         |
| 111                      | SP_WRX1000_V2_71     | Pull rod                                                   |
| 112                      | SP_WRX1000_V2_72_OAK | Pull rod wood for oak device                               |
| 113                      | SP_WRX1000_V2_73_WN  | Pull rod wood for walnut device                            |
| 114                      | SP_WRX1000_V2_74     | Cross recessed countersunk head tapping screws ST3,9 x 15L |
| 115                      | SP_WRX1000_V2_75     | Fore support plate universal wheel                         |
| 116                      | SP_WRX1000_V2_76     | Water tank lower cover                                     |
| 117                      | SP_WRX1000_V2_77     | Silicone loop                                              |
| 118                      | SP_WRX1000_V2_78     | Resistance regulating box                                  |
| 119                      | SP_WRX1000_V2_79     | Resistance regulator top cover                             |
| 120                      | SP_WRX1000_V2_80     | Resistance regulator lower cover                           |
| 121                      | SP_WRX1000_V2_81     | Screw cap                                                  |
| 122                      | SP_WRX1000_V2_82     | Umbrella head hexagon socket screw M8 x P1,25 x 16L        |
| 123                      | SP_WRX1000_V2_83     | Flat washer D8 x D16 x 1T                                  |
| 124                      | SP_WRX1000_V2_84     | Paddle                                                     |
| 125                      | SP_WRX1000_V2_85     | Blade holder                                               |
| 126                      | SP_WRX1000_V2_86     | Light strip cover                                          |
| 127                      | SP_WRX1000_V2_87     | Cross recessed countersunk head tapping screws ST2,9 x 8L  |
| 128                      | SP_WRX1000_V2_88     | Cross recessed countersunk head tapping screws ST2,9 x 12L |
| 129                      | SP_WRX1000_V2_89     | Shot head cross tapping screw ST3,9 x 18L                  |

| No. in explosion drawing | Item No.             | Descriptions                                                     |
|--------------------------|----------------------|------------------------------------------------------------------|
| 130                      | SP_WRX1000_V2_90     | Hexagon bolt M4 x P0,7 x 25L                                     |
| 131                      | SP_WRX1000_V2_91     | Nylon nut M4 x P0,7                                              |
| 132                      | SP_WRX1000_V2_92     | Elastic cylindrical pin D6 x 30L                                 |
| 133                      | SP_WRX1000_V2_93     | Magnet M6 x D7 x 4L                                              |
| 134                      | SP_WRX1000_V2_94     | Aluminum track left 42 x 16 x 1105L x 2T                         |
| 135                      | SP_WRX1000_V2_95     | Aluminum track right 42 x 16 x 1105L x 2T                        |
| 136                      | SP_WRX1000_V2_96_OAK | Slide rail support plate left 28 x 120 x 1112 for oak device     |
| 137                      | SP_WRX1000_V2_96_WN  | Slide rail support plate left 28 x 120 x 1112 for walnut device  |
| 138                      | SP_WRX1000_V2_97_OAK | Slide rail support plate right 28 x 120 x 1112 for oak device    |
| 139                      | SP_WRX1000_V2_97_WN  | Slide rail support plate right 28 x 120 x 1112 for walnut device |
| 140                      | SP_WRX1000_V2_98_WN  | Sliding seat rear support plate for walnut device                |
| 141                      | SP_WRX1000_V2_98_OAK | Sliding seat rear support plate for oak device                   |
| 142                      | SP_WRX1000_V2_99_OAK | Sliding seat front support plate for oak device                  |
| 143                      | SP_WRX1000_V2_99_WN  | Sliding seat front support plate for walnut device               |

# SPAREPARTS-OVERVIEW / ERSATZTEILLISTE